



# Matching instruction for remote and wireless LED beacon


 When you do the process ,please make sure the battery of the light has enough battery

When you do the process ,please make sure the light and the remote in signal communicate range


**1** Press “ON/OFF” 5times Continuously With in 2.5Sec



**2** The green light of the battery indicator with light up for 30seconds



**3** During This period ,Press any button of the Remote once , Then the green light extinguish , the matching process completed,



1. 1light can match 2 remotes max

2. 1remote can match 10 led beacons max

