## **FLASH PATTERNS**

Momentarily push flash pattern button:

· Once for next pattern

|     | 10 M                     |
|-----|--------------------------|
| FP# | Flash Patterns           |
| 0   | Random                   |
| 1   | Rotating                 |
| 2   | Single (split)           |
| 3   | Double (split)           |
| 4   | Quad (split)             |
| 5   | Quint (split)            |
| 6   | Mega (split)             |
| 7   | Ultra (split)            |
| 8   | Single-Quad (split)      |
| 9   | Single H/L (split)       |
| 10  | Single (all)             |
| 11  | Double (all)             |
| 12  | Quad (all)               |
| 13  | Quint (all)              |
| 14  | Mega (all)               |
| 15  | Ultra (all)              |
| 16  | Single-Quad (all)        |
| 17  | Single H/L (all)         |
| 18  | Steady 2 (california)    |
| 19  | Single (2Hz)             |
| *20 | Double (Reg 65 approved) |
| 21  | Triple (2Hz)             |
| 22  | Quad (2Hz)               |



Model: with Dual button cigar-plug.



## WARNING:

The lightbar should be parallel with the ground and fitted to the flattest part of the roof in the longitudinal centre line. The vehicle panel must be made of steel construction and covered only with the manufacturers normal paint finish

It is not recommended to use magnetically mounted warning devices on vehicles in motion. Usage is at the sole risk and responsibility of the user.