
strands®
-lighting division

MANUAL

SIBERIA SKYLORD 9"


RED = +VDC
BLACK = - TO CHASSIS GROUND
WHITE = WHITE POSITION LIGHT
YELLOW = AMBER POSITION LIGHT



HOW TO CONTROL XPERIENCE MODE:
When you start the Driving light for the first time, it is set to E-mode (E-approved mode).

To switch to Xperience mode, turn on the high beam for 2 seconds, then flash the high beam 3 times within 5 seconds.

To switch back to E-mode, turn off the high beam for 5 seconds, let the high beam run for 2 seconds, then flash the high beam 3 times within 5 seconds.



READ THIS BEFORE INSTALLATION
READ ALL INSTRUCTIONS AND STUDY DIAGRAMS BEFORE INSTALLING YOUR NEW LIGHTS!

LEGAL MOUNTING
Check with state or local authorities for laws governing usage and proper mounting of your new lights.

TAKE CARE OF YOUR PRODUCT
Keep the product clean. Dirt on the lens and heat-sink may shorten the products lifetime.

We recommend using lukewarm water and alkaline degreasing.
Follow the degreasing instructions carefully and rinse off gently with cold or lukewarm water on low pressure.

WARNING!
Strong chemicals should not be used on the product. If you accidently get strong chemicals on the product, rinse off immediately, use plenty of water so that no chemicals remain in any joint.
Some chemicals have a small amount of solvent in them, this can dissolve sealing adhesives and compromise the product's waterproofness.
Some chemicals pull out liquid from plastic and rubber-based components, which makes the plastic or rubber brittle and bursts more easily.
Be careful not to use high water pressure close up on the product.
If you use high water pressure at short distances, most products find it difficult to close out the water.

INSTALLATION
If there is a contact/connector on the product, it should not be cutted. If the connector is cut, the warranty is not valid.

If the product has loose cable and no connector. If the cable is shorter than 50 cm, the cable must not be cutted. If the cable is cut, the warranty is not valid.
If the cable is longer than 50 cm, it is ok to shorten the cable, but not shorter than 50 cm.
If the cable is cut shorter than 50 cm, the warranty is not valid.

Tighten screws and bolts so that they do not loosen or chafe.
Do not tighten screws so hard that the protective bearings on the product breaks.

WARNING!
Do not use higher volts than the product description states.
This light becomes hot under continuous use. Don't remove or touch the casing for at least 30 minutes after turning the lamp off.

Part no. 270948

Contact us if you need support: support@strands.se or +46(0)320-450450

3 YEARS FUNCTION WARRANTY

www.strands.se
www.strandseurope.com